


Backverriegelung



Radio Code







FUNKTIONEN KONTROLLIEREN
FUNKTIONSTEST
CHECK FUNCTIONS
CONTROLEER FUNCTIES

MERCEDES W210/S210 1995- CLK C208 1997-


- D** Einbauanweisung
Elektrischer Zubehörsatz
- GB** Installation Instructions
Electrical Accessories Set
- F** Instructions de montage
Jeu d'accessoires électriques
- I** Istruzioni di montaggio
Kit di montaggio elettrico
- E** Instrucciones de montaje
Juego de accesorios eléctrico
- NL** Inbouwhandleiding
Elektrisch Toebehoorpakket




INFO + ROUTING W210 / S210





W210 + S210



C208




- X kann 4-, 12- oder 18-polig sein
Siehe in der Tabelle für die richtige Position
- X kan vara 4-, 12- eller 18 pol
se tabell för rätt position
- X can be 4-, 12- or 18-pole
See table for the right position
- X kan 4-, 12- of 18-polig zijn
Voor de juiste positie zie tabel




Poles	X	Position
4	→	2
12	→	2
18	→	15


INFO + ROUTING C208




W210




S210




W210+S210




C208




13p



13p




13p




13p



W210+S210





13p C208





13p OPTIE 208





C208



10 mm




C208



W210


S210

C208






W210+S210

C208



W210+S210



C208

